

**Leneta Company, Inc.**

15 Whitney Rd.

Mahwah, NJ, 07430 USA

**Phone:** 201.847.9300 • **Fax:** 201.848.8833**Email:** [sales@leneta.com](mailto:sales@leneta.com) • **Website:** [www.leneta.com](http://www.leneta.com)**Form 24B Gray Scale Chart**

Form 24B is a white, light gray and black gray scale chart. The chart is with six stripes on white field.

The stripes on this chart are numbered 1 to 6, representing uniform steps of increasing contrast. The hiding power of the applied coating is rated as the number of the darkest stripe that is completely (or almost completely) obscured, at a specified thickness or spreading rate. Paint is usually applied to this chart using a drawdown blade rather than brush or roller.

**Specifications**

<b>Color</b>	White, Light Gray & Black
<b>Size</b>	7-5/8 x 11-3/8 in 194 x 289 mm
<b>Box Quantity</b>	250
<b>Boxes per Case</b>	4
<b>Box Weight</b>	9 lb