



ADM 2

Variable Speed Draw-Down

Our best seller

Get consistent use of grind gages using the ADM 2 automatic draw-down machine from Little Joe Industries. The ADM 2 is designed to be durable and simple to operate.

- Designed for use with liquid and paste coatings.
- Adjustable draw down speeds from one to ten seconds
- Consistent and accurate scraper force adjustable from 1.75 to 6 kg (3.5 to 13 pounds).
- Smooth motorized scraper movement.
- Rigidly held scraper provides consistent scraper angle.
- Uses existing grind gauges and scrapers from your current supplier.
- Works with grind gauges and with draw-down pads.
- Requires less operator training and supervision on proper grind gage use.
- Removes operator variables.

The scraper is held at an 85-degree angle. This allows using each side of the scraper twice, effectively giving you four scraper edges instead of just two and doubling the life of each scraper compared to a 90-degree angle. 90-degree versions are available [\[Link\]](#) by special order.

The ADM also makes color comparison draw downs on draw down pads using a scraper. This requires the purchase of a Draw Down Kit [\[Link\]](#).

Specifications:

Minimum scraper force: 1.75 kg

Maximum scraper force: 6 kg

Maximum grind gage size: 25 cm long x 11 cm wide

Speed: Variable

Scraper angle: 85 degrees

Power: 100/120 v or 200/240v; 50/60hz

Fuse: 1 amp slow burn