

CERALENE[®] 850

Product description **Polypropylene wax** **CAS-No.: 9003-07-0**

CERALENE[®] 850 is a high crystalline polypropylene homopolymer wax.

Characteristic	Unit	Target value
Appearance	-	almost white prills
Density (23°C)	g/cm ³	0.91
Drop point	°C	152
Viscosity (170°C)	mPa*s	80
Penetration (25°C)	mm*10 ⁻¹	< 1
Acid value	mg KOH/g	0

Major fields of application

For different kinds of technical applications like pigment wetting and dispersion in PP masterbatches, modification of hot melts and bitumen. CERALENE[®] 850 is recommended for the production of PP fibre masterbatches, especially in combination with CERALENE[®] 694 (dosage level of CERALENE[®] 694 typically between 15 – 25% based on the total wax content in the masterbatch).

Packaging

PE-bags of 20 kg netto
Palett of 1000 kg (50 bags)
Big bags of 1000 kg netto

Storage

The product has to be stored dry at room temperature.
Beware of sunlight and heat.
Stability at least 2 years from date of delivery.

Hazards

This product does not require labelling in terms of preparation guideline. Further security relevant data see safety data sheet.

Ecology/toxicology properties

Acute oral toxicity LD₅₀: > 2000 mg/kg (rat)
The product is water insoluble and shows no harmful effects on fish and bacteria.

Status under food legislation

The product fulfills legislations of various countries. More details on request.

All information given here are based on our own research or the research of others and believed to be accurate and shall give the user guidance for the application. Nevertheless these data are no specification and due to the versatile possible formulations, applications, processings and further parameters at the formulator/user the usage of this product has to be tested carefully in the particular system/application by the formulator/user. All information mentioned here are not warranted properties. There is no responsibility of the seller if the material is used outside the recommended field of use; any liability, also for any patent infringement, cannot be derived from this.

version 2.0 15.04.2015