

SILCO SPERSE HLD-19 N

Product Description:

High performance dispersing additive for solventbased and plastisized pigmented systems

Technical Data:

Form supplied : clear liquid

Active ingredient: polymeric dispersant

Active agent : > 96%

Ionic character : anionic

pH-Value : n.a.

Processing : Add to the mill base before premix. Guiding formulations are available on request.

Dosage : 1 – 5% on mill base

Properties:

SILCO SPERSE HLD-19 N is used in

* solventbased inks and coatings

* PVC plastisols

with

- * excellent wetting or dispersing power for inorganic pigments & carbon black
- * excellent colour strength development
- * free of alkylphenolethoxylates
- * free of solvents

Storage:

SILCO SPERSE HLD-19 N is stable for at least 24 months at room temperature. Please avoid temperatures under 4°C and over 50°C.

FDA-/BfR-Rules:

FDA : please contact us

BfR : please contact us

Transport Classifications:

ADR. : refer to MSDS

IMCO : refer to MSDS

UN-NR : refer to MSDS

EEC-Labeling Requirements:

Symbol : refer to MSDS

R-S : refer to MSDS

S-S : refer to MSDS

Packaging:

- 25 kg hobbock
- 120 kg drum
- 1000 kg container

This leaflet gives the user guidance and information but does not claim to be complete and is without any obligation.

revision: 0/DL

issue date: 06.November 2012