

SILCO SPERSE HLD-25

Product Description:

High performance dispersing agent for water based paint and coating systems.

Technical Data:

Form supplied:	yellowish liquid
Active ingredient:	salt of polymeric dispersants with groups of high pigment affinity
Total solids:	29 - 31%
Ionic character:	anionic
pH-Value:	8.0 – 10.0
Processing:	Add to the mill base before premix. Guiding formulations are available on request.
Dosage:	Recommended level is 10 – 35% on pigments

Properties:

SILCO SPERSE HLD-25 can be used in

- industrial colorants
- paints and coatings

with

- excellent wetting and dispersing power especially for transparent iron oxides
- free of alkyphenoethoxylates

Storage:

SILCO SPERSE HLD-25 is stable for at least 12 months at room temperature. Please avoid temperatures under 4°C and over 50°C.

FDA-/BfR-Rules:

FDA: please contact us
BfR: please contact us

Safety and MSDS:

For regulatory details such as the classification and labelling as dangerous substances or goods please refer to our corresponding Material Safety Data Sheet.

Packaging:

- 25 kg hobbock
- 120 kg drum
- 1000 kg container

This leaflet gives the user guidance and information but does not claim to be complete and is without any obligation.

revision: 3/PS
issue date: 25.Juli 2017