

# SILCO WET D-504/E

## Product Description:

Siloxane free high performance wetting agent for water based inks and coatings.

## Technical Data:

Form supplied:	clear yellowish liquid
Active ingredient:	TMDD in ethylene glycol
Active content:	49% - 51%
Ionic character:	non ionic
pH-Value:	not applicable
Processing:	SILCO WET D-504/E is added under stirring to the coating formulation
Dosage:	0.1 – 1.0% based on total formulation

## Properties:

SILCO WET D-504/E is used in water based

- industrial coatings
- printing inks

in order to efficiently improve

- surface wetting
- defoaming properties
- levelling properties
- reduce the surface tension of coatings  
(to a minimum of 28 mN/m)

## Storage:

SILCO WET D-504/E is stable for at least 15 months at room temperature. Please avoid temperatures under 5°C and over 40°C.

## FDA-/BfR-Rules:

FDA: please contact us

BfR: please contact us

## Safety and MSDS:

For regulatory details such as the classification and labelling as dangerous substances or goods please refer to our corresponding Material Safety Data Sheet.

## Packaging:

- 30 kg hobbock
- 120 kg drums
- 1000 kg container

This leaflet gives the user guidance and information but does not claim to be complete and is without any obligation.

Revision: 2/PS  
Issue date: 24.July 2017