

SILCO WET D-505

Product Description:

VOC-free and silicon free high performance wetting agent for waterbased inks and coatings

Technical Data:

form supplied : clear yellowish liquid
active ingredient : compound of aliphatic polymers
active content : 84% - 86%
ionic character : non ionic
pH-Value : not applicable
Processing : SILCO WET D-505 is added with stirring to the coating formulation
Dosage : 0.1 – 1.0% based on the whole formulation

Properties:

SILCO WET D-505 is used in VOC-free waterbased

- * industrial coatings
- * printing inks

in order to efficiently improve

- * surface wetting
- * non foaming properties
- * levelling properties
- * reduce the surface tension of inks and coatings to a minimum of 27 mN/m

Storage:

SILCO WET D-505 is stable for at least one year at room temperature. Please avoid temperatures under 5°C and over 40°C.

FDA-/BfR-Rules:

FDA : please contact us
BfR : please contact us

Transport Classifications:

ADR. : refer to MSDS
IMCO : refer to MSDS
UN-NR : refer to MSDS

EEC-Labeling Requirements:

Symbol : refer to MSDS
R-S : refer to MSDS
S-S : refer to MSDS

Packaging:

- 30 kg hobbock
- 120 kg drums
- 1000 kg container

This leaflet gives the user guidance and information but does not claim to be complete and is without any obligation.

Revision: 2/DL
Issue date: 09.February 2011