

SILCO WET D-550

Product Description:

High performance APEO-free polymeric wetting agent, suitable for food and tobacco packaging inks

Technical Data:

form supplied	: clear liquid
total solids	: > 98%
ionogenity	: nonionic
pH value	: n.a.
Processing	: SILCO WET D-550 is added with stirring to the coating formulation
Dosage	: 0.1 – 5.0% based on the whole formulation

Properties:

SILCO WET D-550 is used

- * in waterbased DFC inks
- * in waterbased low migration coatings
- * as APEO and alkandiole substitute

in order to

- * decrease surface tension
- * improve flow and leveling properties
- * accelerate pigment wetting

Storage:

SILCO WET D-550 is stable for at least one year at room temperature. Please avoid temperatures under 0°C and over 40°C.

FDA-/BfR-Rules:

FDA : please contact us
BfR : please contact us

Transport Classifications:

ADR. : refer to MSDS
IMCO : refer to MSDS
UN-NR : refer to MSDS

EEC-Labeling Requirements:

Symbol : refer MSDS
R-S : refer MSDS
S-S : refer MSDS

Packaging:

- 30 kg hobbock
- 120 kg drums
- 1000 kg container

This leaflet gives the user guidance and information but does not claim to be complete and is without any obligation.

Revision: 1/DL
Issue date: 04.February 2011